




-1.00 - 2.00
0.00 - 1.00
0.00 - 1.00
1.00 - 2.00
2.00 - 3.00
3.00 - 4.00
4.00 - 5.00
5.00 - 6.00
6.00 - 7.00
7.00 - 8.00
8.00 - 9.00
9.00 - 10.00
10.00 <

DATUM ETRS89 UTM HUSO 29